

21 Terminal Cover
22 [DC IN] Socket
23 [DIGITAL] / [AV OUT] Socket (DMC-LC70)
[DIGITAL] / [V.OUT] Socket (DMC-LC50)
24 Card Door



25 Tripod Receptacle
26 Battery Door